


**Thank you for purchasing an ApplianX IP Gateway from Aculab**

Your order contains:


- ApplianX IP Gateway
- Power cable
- Quick start guide

Follow these steps to prepare the ApplianX IP Gateway for use:

- Connect the power cable to rear of chassis and plug into mains supply.



- Your ApplianX IP Gateway will light the front panel LEDs, in a sequence, where some flash and some remain lit. Soon after the blue 'Activity' light stops flashing, the gateway will settle into a state with the 'Initialising' and 'Warning' lights permanently lit. The gateway is ready to be configured.



- ApplianX IP Gateway configuration is carried out using a web browser. This can be achieved by connecting the auto sensing 'Admin' Ethernet port of the gateway directly to a PC. The gateway is shipped with a default IP address of 192.168.1.100 and a subnet mask of 255.255.255.0.
- Configure the PC with an IP address in the same subnet and open a web browser. To access the gateway browse to 192.168.1.100. Alternatively, you can use the ApplianX Search Tool to gain access.
- Once the ApplianX IP Gateway is accessed you will be asked to set up an administration username and password. You will then be taken through the configuration wizard. At the end of this wizard, you will be directed to the main configuration page, where you can activate your gateway.
- For more detailed instructions please see the ApplianX IP Gateway user guide, which is available from: <http://www.aculab.com/documents/browse/?tag=applianx>

**If you have any issues with your ApplianX IP Gateway, please contact: [support@aculab.com](mailto:support@aculab.com)**

Owing to the dynamic nature of our business, specifications are constantly being changed and, therefore, this quick start guide is for informational purposes only. Aculab makes no warranties, express or implied, in this document. E&OE.